

BULUCUT-2 ABRASIVE CUTTER



CE

BMS Bulut Makina Sanayi ve Ticaret Ltd. Şti.
Kocaeli KOBİ Organize Sanayi Bölgesi
Köseler Mahallesi, 6.Cadde No: 20/2 Dilovası / KOCAELİ / **TURKEY**
Phone: +90 262 502 97 73-76 / +90 262 503 06 51
Web: www.bulutmak.com e-mail: bms@bulutmak.com

1	DESCRIPTION	3
2	TECHNICAL SPECIFICATIONS	3
3	STANDART ACCESSORIES	3
4	UNPACKING	6
5	INSTALLATION	6
6	PLUMBING	6
7	CUTTER WHEEL LOCATING	6
8	CUTTING FLUID MANUAL	7
8.1	FIRST TIME FILLING OF RESERVOIR TANK	7
8.2	ADDING CUTTING FLUID AFTER SOME PERIOD OF USAGE	7
8.3	SAMPLE FIXING	7
8.4	CUTTING OPERATION	7
9	LED LIGHT SYSTEM	7
10	PART LIST	8

1 DESCRIPTION

Abrasive Cutter

Sturdy table model for sectioning Metals, Ceramic and mineral samples.

Corrosion resistance GRP cover with see - through hood.

Special Aluminum casted heavy robust base.

Easy use twin cam actuated vises for holding samples.

All inside parts made from stainless steel or chromium plated steel.

Splash proof during cutting.

Cooling by two high flow water jets to provide optimum cutting.

Cutting action provided by moving motor on specimen.

11 W light illuminator protected from water in specially isolated cover fixed inside the cover to obtain safe and clear illumination on cutting area.

Separately mounted recirculation coolant tank with large drain.

57 ltr capacity coolant tank, suitable filtering part provided to filter the slugs formed during cutting.

2 TECHNICAL SPECIFICATIONS

Machine dim's	650x700 x1600 mm
Case dim's inc. cooling system	1000x1000x1600 mm
Weight (net/gross)	130 / 200 kg
Motor	3 KW, AC 380 Volt, Three phase 2850 rpm
Cutting system	Manual
Table dimensions	T-slotted clamping table(370 x 173 mm) (1 pcs)
Clamping devices	Fast cam locking vises (2 pcs)
Cutting capacity	90 mm dia
Cutting wheel size	250 X 32 X 1,6 (1,5) mm
Coolant pump	380 Volt, Three phase , 0,12 KW
Coolant reservoir dim's	600 x 400 x 300 mm, 57 ltr capacity

3 STANDART ACCESSORIES

Abrasive cutter,

Recirculating cooling system

Two coolant circulation hoses and clips,

Arrow wrench and pin.

250 mm, 5 abrasive cutting wheels,

Cutting fluid (5lt)

Fast cam locking vise clamping devices (2 pcs)



TOP COVER SAFETY SWITCH (Top cover opens after 10 sec. when the cutting proses is done or machine has the energy) waiting time can be adjustable

STOP



START



LAMP



PUMP



TOP COVER

CUTTING
LEVER

SEE THROUGH
HOOD

BULUCUT
ABRASIVE CUTTER

ELECTRIC
PANEL



SAFETY
SWITCH

BASE OF
CUTTER


POWER

LEVELLING
BOLT





(Rear of Machine)



4 UNPACKING

Remove packing materials and lift out machine complete with baseboard. Remove 4 securing bolts that secures machine to baseboard.

5 INSTALLATION

Open cover. (01)

Remove the shipping strap from the cutting head and push the cutting lever (26) to the rear to raise the cutting Wheel (18) as high as possible.

Install the cutter on suitable table and secure alignment by means of adjusting positions of 4 secure leveling bolts. (03)

Plug to mains 380-400V (3 phase) power and check the turning position of cutter and ensure correct turning if necessary.

LEVELING BOLT



6 PLUMBING

Locate recirculation pump on its table and bring it to the near of cutter.

Make recirculation pump electrical connections Connect 18 mm coolant supply hose to the rear of cutter and tighten the hose clamp. Locate the other end to recirculation pump and tighten the hose clamp.

Connect the 40 mm dia coolant return hose to rear of cutter and clip the hose clamp. Locate other end of hose on filter of reservoir tank

Fill the reservoir tank with water (55 liter) and %5 (3 liter) of cutting fluid. Locate top cover on tank.

Open the cover of cutter and press PUMP button and allow pump to run a few minutes. This procedure ensures adequate mixing of coolant solution. (PUMP button is not used when the cover is closed.)

7 CUTTER WHEEL LOCATING

Please pay attention while installing abrasive cutting wheel. Do not use wheel dia greater than 250 mm and thickness 1,8 mm.

Raise cover (01) and remove the Wheel guard. (20) Insert the arbor pin into hole of bushing (19) and using 36 mm wrench loosen the wing nut (16) (Bushing of motor spindle has left hand thread) and locate the cutter.(18) wheel in position perfectly.

Make the same procedure to ensure tighten of wing nut as well. Never leave arbor pin inserted into hole of bushing (19)

Make sure two faces of wheel and bushing clean.

8 CUTTING FLUID MANUAL

8.1 First Time Filling Of Reservoir Tank

- Obtain separate tank for mixing. (For example 25 ltr. plastic tank)
- Fill tank with water.(For example 20 ltr) Later ,add ,%5 CIMSTAR 506 cutting fluid (or its compatible) (1 ltr for 20 ltr water)
- While adding, cutting fluid to water slowly, mix well
- Put this mixed fluid to reservoir tank.

8.2 Adding Cutting Fluid after Some Period of Usage

- In case of requirement of adding cutting fluid after first time filing, followings to be considered.
- Fill plastic tank with water. (For example 20 ltr.) Later, add %3 CIMSTAR 506 Cutting fluid (For 20 ltr water 0.6 ltr cutting fluid.)
- While adding, cutting fluid to water slowly, mix well
- 4) - Put this mixed fluid to reservoir tank.

After each month of usage we recommend you to clean reservoir tank and add new cutting fluid as first time filling.

8.3 Sample Fixing

Two wises positioned at our works for general purpose of cutting.

When required for larger samples, it can be necessary to reposition the wises nearer to the front of the machine. For this purpose, loosen 4 bolts of fixing plate of holding fixture. Locate the sample on fixed jaw (07) and push forward clamping jaw (08) against sample. Use a suitable pressure and push clamping lever (13) tightly. Do not over clamp.

8.4 Cutting Operation

Be sure sample is clamped and jaws tighten well.

Close the cover. (The cutter will not operate unless the cover is completely closed)

Start cutting and pump motors by pressing **START button**. (**Do not start motors when cutting lever is in mid position and be sure cutting wheel is not touching the sample**)

Check the flow of coolant and adjust the flow of water jets if required

Slowly feed the cutter wheel on sample by pulling cutting lever. (17)

To reach constants cutting range maintain pressure as required. (Excessive force may cause motor overload and damage cutter wheel.)

When cutting procedure is completely finished, bring the cutting lever to its starting position.

Cutter wheel rotates for several seconds after pushing STOP button or opening cover. In case of opening cover, please be sure cutter wheel completely stopped.

9 LED LIGHT SYSTEM



LED 24V DC, 8,4W /1 MT

10 PART LIST

Part Nr	Part name	Part Nr	Part name
1	cover	14	Pushing rod
2	Base of cutter	15	Vises
3	Leveling bolt	16	Wing nut
4	Fixing plate of vise section	17	Plate
5	Pin	18	Cutter wheel
6	Vise plate	19	Bushing
7	Fixed jaw	20	Wheel guard
8	Clamping jaw	21	Motor
9	Top plate of swiveling arm	22	Fixing bush
10	Swiveling bushing	23	Bearing housing
11	Holding fixture	24	Fixing plate of motor
12	Egzantric cam	25	Rotating spindle
13	Clamping lever	26	Cutting lever